

# DS-1273ZJ-160B


Wall Mounting Bracket for Dome Camera

# (With junction box)

### Features:

- Aluminum alloy material with surface spray treatment
- Design with cable entry hole
- Better water proof design
- Convenient installation coordinating with cap

#### **Dimension:**



## **Order Model:**

DS-1273ZJ-160B



### Parameter:

Model	DS-1273ZJ-160B
	Wall Mounting Bracket for
Parameters	Dome Camera(with junction box)
Appearance	Hik White
Range of	Suitable for dome camera wall mounting
Application	-
Material	Aluminum Alloy
Dimension	160×243×303mm
Weight	1630g

## Notice:

- The bracket is for dome camera
- Pay attention to color matching
- The bracket should be installed on flat wall
- The wall must be capable of supporting over 3 times as much as the total weight of the camera and the mount.
- The maximum load capacity of the bracket is 4.5KG

# Model Suitable:

DS-2CD72XXF-E(I)Z(H)(S),DS-2CD72X3PF-E(I)Z(H)(S),DS-2CD72X3NF-E(I)Z(H)(S),DS-2CD7293PFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD7293NFWD-E(I)Z(H)(S),DS-2CD720NFWD-E(I)Z(H)(S),DS-2CD720NFWD-E(I)Z(H)(S),DS-2CD720NFWD-E(I)Z(H)(S),DS-2CD720NFWD-E(I)Z(H)(S),DS-2C E(I)Z(H)(S),DS-2CD72X4FWD-E(I)Z(H)(S),DS-2CD4312F(WD)-(I)(Z)(H)(S),DS-2CD4324F-(I)(Z)(H)(S),DS-2CD4332FWD-(I)(Z)(H)(S)

## Installation Step:

(1) Choose the appropriate wall to fix the junction box



(2) Wiring through



B

(3) Install bracket to junction box;

wiring and screw up

(4) Fix cap to bracket and fix with fastening screw; wiring



- A: Fastening screw
- (8) Installation Complete




(5) Take off the lower dome and inner module



6 Complete wiring and fix inner module to cap







Note: The actual bracket may vary from the picture above.